

# Installation instructions **KAFLEX** post

## Installation steps



### 1. Preparation

Subsurfaces must have sufficient stability and be dry, level and free of dust, silicone and grease.

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.




### 2. Open the grommet at the slit

KAFLEX post has a slit and punched opening for the cable to be sealed. Gently pull the grommet apart at the slit.



### 3. Align the grommet

Guide the grommet with the slit around the cable and align it.



### 4. Stick the grommet to the subsurface

Gradually remove the lower release paper.

Guide the grommet so that it rests flat on the subsurface to be sealed and stick it in place all the way around.

Rub the tape firmly in place using the pro clima PRESSFIX application tool. Ensure that there is sufficient resistance pressure.



### 5. Remove the remaining release film

Finally, remove all of the release paper strips at the folded flaps



### 6. Rub onto the cable

Stick the folded flaps to one another and to the cable in an airtight manner, and rub firmly in place.

Ensure there is good adhesion in the corners.

You're finished!

## Substrates

Clean subsurfaces before sticking.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Install the cables without strain, fix cables with a cable clip as required.

A permanent bond is achieved on all pro clima indoor and outdoor membranes, other vapour check and airtightness membranes (e.g. PE, PA, PP and aluminium foil) as well as roof and wall lining membranes (e.g. PP and PET).

Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood fibre underlay panels).

Pretreatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels and smooth mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

## General conditions

The bonds should not be subjected to tensile strain.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure.

Windproof, airtight or rainproof bonding can only be achieved on vapour checks, roof underlays or wall lining membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

---

### MOLL

**bauökologische Produkte GmbH**

Rheintalstraße 35 - 43

D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0

eMail: [info@proclima.de](mailto:info@proclima.de)